

SECTION 15514 - SAMPLE SPECIFICATION FOR RBI FUTERA III MODULATING BOILER**PART 1 - GENERAL****1.1 RELATED DOCUMENTS**

- A. Drawings and general provisions of the Contract, including General and Supplementary Conditions and Division 1 Specification Sections, apply to this Section.

1.2 SUMMARY

- A. This Section includes gas fired, non-condensing copper tube boilers for heating hot water.
- B. Related Sections include the following:
 - 1. Division 15 Section "Breechings, Chimneys, and Stacks" for connections to breechings, chimneys, and stacks.
 - 2. Division 15 Section "Feedwater Equipment" for connections to condensate and feedwater system.
 - 3. Division 15 Sections for control wiring for automatic temperature control.

1.3 SUBMITTALS

- A. Product Data: Include rated capacities; shipping, installed, and operating weights; furnished specialties; and accessories for each model indicated.
- B. Shop Drawings: Detail equipment assemblies and indicate dimensions, required clearances, and method of field assembly, components, and location and size of each field connection.
 - 1. Wiring Diagrams: Detail wiring for power, signal, and control systems and differentiate between manufacturer installed and field installed wiring.
- C. Source Quality Control Tests and Inspection Reports: Indicate and interpret test results for compliance with performance requirements before shipping.
- D. Field Test Reports: Indicate and interpret test results for compliance with performance requirements.
- E. Maintenance Data: Include in the maintenance manuals specified in Division 1. Include parts list, maintenance guide, and wiring diagrams for each boiler.

1.4 QUALITY ASSURANCE

- A. Listing and Labeling: Provide electrically operated components specified in this Section that are listed and labeled.
 - 1. The Terms "Listed" and "Labeled": As defined in NFPA 70, Article 100.
 - 2. Listing and Labeling Agency Qualifications: A "Nationally Recognized Testing Laboratory" as defined in OSHA Regulation 1910.7.
- B. ASME Compliance: Boilers shall bear ASME "H" stamp and be National Board listed.
- C. CSD-1 Compliance: Control devices and control sequences according to requirements of CSD-1.

- D. FM Compliance: Control devices and control sequences according to requirements of FM.
- E. IRI Compliance: Control devices and control sequences according to requirements of IRI.
- F. Comply with NFPA 70 for electrical components and installation.

1.5 COORDINATION

- A. Coordinate size and location of concrete bases. Concrete, reinforcement, and formwork requirements are specified in Division 3 Section "Cast-in-Place Concrete."

1.6 WARRANTY

- A. General Warranty: The special warranty specified in this Article shall not deprive the Owner of other rights the Owner may have under other provisions of the Contract Documents and shall be in addition to, and run concurrent with, other warranties made by the Contractor under requirements of the Contract Documents. Installing contractor shall provide one year of warranty parts and labor.
- B. Special Warranty: Submit a written warranty, executed by the contractor for the heat exchanger.
 - 1. Warranty Period: Manufacturer's standard, but not less than 10 years from date of Substantial Completion on the heat exchanger. Warranty shall be non-prorated and not limited to thermal shock. Additional 20 year thermal shock warranty on heat exchanger.

PART 2 - PRODUCTS

2.1 MANUFACTURERS

- A. Available Manufacturers: Manufacturer shall be a company specializing in manufacturing the products specified in this section with minimum five (5) years experience. Subject to compliance with requirements, manufacturers offering boilers that may be incorporated into the Work include, but are not limited to, the following:
- B. Design: Boilers shall be CSA design certified as a non-condensing boiler. Boilers shall be designed for a minimum of 3:1 continuous turn down with constant CO₂ over the turndown range. The boiler shall operate with natural gas or propane and have an CSA certified input rating as noted on the drawings, and a thermal efficiency rating of 85% at rated input and 88.3% at minimum input. The boiler shall incorporate a **TrueFlow™** fuel-air system, which is symmetrically air-fuel coupled such that changes in combustion air flow or flue flows affect the BTUH input without affecting combustion quality. The boiler will automatically adjust input for altitude and temperature induced changes in air density. The boiler will use a proven pilot interrupted spark ignition system. The boiler shall use a UL approved flame safeguard ignition control system using UV detection flame sensing. The design shall provide for silent burner ignition and operation. Burner shall be premix radial-type and fire in a 360° vertical pattern. Boiler shall be able to vent a horizontal distance of 60 equivalent feet.
- C. Service Access: The boilers shall be provided with stainless steel jacket panels, minimum 16 gauge, with push-button fasteners for easily accessing all serviceable components. Sheet metal screws may not be used in the securing of jacket panels to the boiler. The boilers shall not be manufactured with large enclosures, which are difficult to remove and reinstall. All accesses must seal completely as not to disrupt the sealed combustion process. All components must be accessible and able to adjust with the removal of a single cover or cabinet component.

- D. Indicating Lights: Each boiler shall include a diagnostic control panel with a full text display indicating the condition of all interlocks and the BTUH input percentage. Access to the controls shall be through a swing-access door, leaving diagnostic panel intact and not disrupted.
- E. Manufacturers: RBI (a Mestek Company) is the basis of design. Listed acceptable manufacturers shall be subject to compliance with requirements. Provide boilers by one of the following:
 - 1. Patterson-Kelley - *Modufire Series Only*
 - 2. Thermal Solutions - Evolution
 - 3. Lochinvar Corp.- *PowerFin Series Only*

2.2 COMPONENTS

- A. Combustion Chamber: The combustion chamber shall be constructed of minimum 16-gauge stainless steel. Aluminum or galvanized steel is not acceptable. An access door shall be provided for ease of service and inspection of the heat exchanger.
- B. Heat Exchanger: The heat exchanger shall be inspected and bear the A.S.M.E. Section IV seal of approval. The heat exchanger shall be a four-pass heat exchanger with a maximum working pressure of 160 psi. The heat exchanger's vertical design shall provide equal amounts of heat transfer throughout the entire heating surface. Each heat exchanger shall have copper tubes, with an integral copper finned tube of 7/8" I.D., .064" minimum wall thickness, 7 fins per inch, with a fin height of 3/8". Each end of the water tubes shall be strength rolled into the header. The heat exchanger shall be gasket-less. Each individual tube can be re-tubed without the disturbance of the surrounding tubes. A pressure relief valve of 50 lb/hr. shall be equipped with the boiler and factory mounted. The headers shall be of bronze construction only; cast shall not be acceptable.
- C. Jackets: 18 Gauge Brushed stainless steel
- D. Gas Burner: Metal fiber mat premix burner shall fire to provide equal distribution of heat throughout the entire heat exchanger. Burner composition shall be Fecralloy™. The burner shall be easily removed for maintenance without the disruption of any other major component of the boiler. Ignition electrodes shall be removed for inspection and proper alignment without removing the burner. A window view port shall be provided for visual inspection of the flame during firing.
- E. Ignition Components: The ignition hardware shall consist of dual Alumina ceramic insulated ignition electrodes and UV sensing tube permanently arranged to ensure proper ignition electrode and UV alignment. Electrodes must be capable of removal while leaving the burner intact. Hot surface ignition systems of any type *will not* be accepted.
- F. Rated Capacity: The boiler shall be capable of operating at rated capacity with pressures as low as 2" W.C. at the inlet to the burner pressure regulator. Boilers that cannot provide full BTUH inputs at 2" W.C. *will not* be accepted.
- G. The burner shall be capable of 88.3% efficiency without exceeding a NOx reading above 10 ppm.

- H. The burner and gas train shall be provided with the following trim and features:
1. Burner Firing: **TrueFlow™** Full modulation with 3:1 turndown @ Continuous CO2
 2. Burner Ignition: Intermittent spark
 3. Safety Controls: Energize ignition, limit time for establishing flame, prevent opening of gas valve until pilot flame is proven, stop gas flow on ignition failure, and allow gas valve to open.
 4. Flue Gas Collector: Enclosed combustion chamber with integral combustion air blower and single venting connection.
 5. Gas Train: Manual gas valves (2), main gas valve (motorized), 'B' valve, pilot gas pressure regulator, and automatic pilot gas valve. All components to be factory mounted.
 6. Safety Devices: Optional high/low gas pressure switches, air flow switch, and blocked flue detection switch. All safeties to be factory mounted.

2.3 BOILER TRIM

- A. Safety Relief Valve: ASME rated, factory set to protect boiler and piping as per schedule/drawings.
- B. Gauge: Combination water pressure and temperature shipped factory installed. LCD inlet/outlet temperature gauges to be an integral part of the front boiler control panel to allow for consistent easy monitoring of temperatures factory mounted and wired.
- C. Flow Switch: Prevent burner operation when water falls below a safe level or when water flow is low. Flow switch shall be factory mounted and wired. Provision for installation of a low water cut off shall be provided.
- D. Operating Controls: Boiler shall be provided with a Honeywell RM7895A series digital flame safe guard. The flame safeguard shall be capable of prepurge cycles.
- E. Operating Temperature Control: Shall be a manual probe type controller adjustable from 120 to 240 degrees F. Control shall be factory mounted and sense the inlet temperature of the boiler through a resistance sensor.
- F. High Limit: Temperature control with manual reset limits boiler water temperature in series with the operating control. High Limit shall be factory mounted and sense the outlet temperature of the boiler through a dry well.
- G. PROVIDE THE FOLLOWING STANDARD TRIM:
1. Low Air Pressure Switch
 2. Blocked Flue Detection Switch
 3. Flow Switch (factory mounted and wired)
 4. Modulation Control
 5. Temperature/Pressure Gauge
 6. Manual Reset High Limit

7. Air Inlet Filter
8. Inlet/Outlet Temperature Display
9. Full Digital Text Display for all Boiler Series of Operation and Failures
10. Variable Frequency Drive and Combustion Air Fan

H. PROVIDE THE FOLLOWING JOB SPECIFIC TRIM AND FEATURES

1. Air inlet hood for exterior termination of air intake pipe. (shipped loose)
2. Vent termination hood for exterior termination of vent pipe. (shipped loose)
3. FM or IRI controls and Gas Train.
4. CSD-1 controls and Gas Train.
5. Diagnostic Keyboard Display for RM7800 series control.

2.4 MOTORS

- A. Refer to Division 15 Section "Motors" for factory installed motors.
- B. Boiler Blower Motor: Open drip-proof motors where satisfactorily housed or remotely located during operation. Blower motor shall be externally mounted for ease of service. There shall be no requirement to remove gas train components to remove the blower motor. Blower Motor *shall not* exceed 3/4 HP and *not* require more than 12 amps.

2.5 SOURCE QUALITY CONTROL

- A. Test and inspect boilers according to the ASME Boiler and Pressure Vessel Code, Section IV. Boilers shall be test fired in the factory with a report attached permanently to the exterior cabinet of the boiler for field reference.

PART 3 - EXECUTION

3.1 EXAMINATION

- A. Examine area to receive boiler for compliance with requirements for installation tolerances and other conditions affecting boiler performance. Do not proceed with installation until unsatisfactory conditions have been corrected.

3.2 INSTALLATION

- A. Install boilers level and plumb, according to manufacturer's written instructions and referenced standards.
- B. Install gas-fired boilers according to NFPA 54.
- C. Support boilers on 4 inch (100 mm) thick concrete base, 4 inches (100 mm) larger on each side than base of unit.
- D. Install electrical devices furnished with boiler, but not specified to be factory mounted.
- E. Install a 3/4" drain valve on the outlet piping prior to the first shut off valve.

3.3 CONNECTIONS

- A. Connect gas piping full size to boiler gas train inlet with union.
- B. Connect hot water piping to supply and return boiler tapings with shutoff valve and union or flange at each connection.
- C. Install piping from safety relief valves to nearest floor drain.
- D. Connect breeching to boiler outlet, full size of outlet. The boiler shall operate under positive (Category IV) or negative (Category II) stack pressure. Vent material must be listed AL29-4C Stainless Double Wall Stack for condensing appliances.
- E. Electrical: Comply with applicable requirements in Division 16 Sections.
- F. Ground equipment.
 - 1. Tighten electrical connectors and terminals according to manufacturer's published torque-tightening values. If manufacturer's torque values are not indicated, use those specified in UL 486A and UL 486B.

3.4 FIELD QUALITY CONTROL

- A. Manufacturer's Field Service: Engage a factory authorized service representative to supervise the field assembly of components and installation of boilers, including piping and electrical connections. Report results in writing.
 - 1. Test and adjust controls and safeties. Replace damaged and malfunctioning controls and equipment.
- B. Manufacturer's representative shall supply a factory authorized service technician to start up the boilers.

3.5 CLEANING

- A. Flush and clean boilers on completion of installation, according to manufacturer's written instructions.
- B. After completing boiler installation, including outlet fittings and devices, inspect exposed finish. Remove burrs, dirt, and construction debris and repair damaged finishes including chips, scratches, and abrasions with manufacturer's stainless steel cleaner.

3.6 COMMISSIONING

- A. Engage a factory authorized service representative to provide startup service. Start up to be performed only after complete boiler room operation is field verified to offer a substantial load, and complete system circulation. One year warranty shall be handled by factory authorized tech.
- B. Verify that installation is as indicated and specified.
 - 1. Verify that electrical wiring installation complies with manufacturer's submittal and installation requirements in Division 16 Sections. Do not proceed with boiler startup until wiring installation is acceptable to equipment Installer.

- C. Complete manufacturer's installation and startup checklist and verify the following:
1. Boiler is level on concrete base.
 2. Flue and chimney are installed without visible damage.
 3. No damage is visible to boiler jacket, refractory, or combustion chamber.
 4. Pressure reducing valves are checked for correct operation and specified relief pressure. Adjust as required.
 5. Clearances have been provided and piping is flanged for easy removal and servicing.
 6. Heating circuit pipes have been connected to correct ports.
 7. Labels are clearly visible.
 8. Boiler, burner, and flue are clean and free of construction debris.
 9. Pressure and temperature gauges are installed.
 10. Control installations are completed.
- D. Ensure pumps operate properly.
- E. Check operation of pressure reducing valve on gas train, including venting.
- F. Check that fluid level, flow switch, and high temperature interlocks are in place.
- G. Start pumps and boilers, and adjust burners to maximum operating efficiency.
1. Fill out startup checklist and attach copy with Contractor Startup Report.
 2. Check and record performance of factory provided boiler protection devices and firing sequences.
 3. Check and record performance of boiler fluid level, flow switch, and high temperature interlocks.
 4. Run-in boilers as recommended or required by manufacturer.
- H. Perform the following tests for each firing rate for high/low burners and for 100, 66, and 33 percent load for modulating burners. Adjust boiler combustion efficiency at each firing rate. Measure and record the following:
1. Inlet gas pressure.
 2. Gas pressure on manifold.
 3. Flue gas temperature at boiler discharge.
 4. Flue gas carbon dioxide and oxygen concentration.
 5. Natural flue draft.

- I. Measure and record temperature rise through each boiler.

3.7 DEMONSTRATION

- A. Engage a factory authorized service representative to train Owner's maintenance personnel as specified below:
 - 1. Operate boiler, including accessories and controls, to demonstrate compliance with requirements.
 - 2. Train Owner's maintenance personnel on procedures and schedules related to startup and shutdown, troubleshooting, servicing, and preventive maintenance.
 - 3. Review data in the maintenance manuals. Refer to Division 1 Section "Contract Closeout."
 - 4. Review data in the maintenance manuals. Refer to Division 1 Section "Operation and Maintenance Data."
 - 5. Schedule training with Owner with at least 7 days advance notice.

END OF SECTION 15514